

Cookies auf der element14-Website

Wir verwenden Cookies, um sicherzustellen, dass wir Ihnen auf unserer Website den besten Service liefern. Wenn Sie die Website weiterhin verwenden, ohne die Einstellungen zu ändern, nehmen wir an, dass Sie damit einverstanden sind, alle Cookies dieser Website zu erhalten. Weitere Informationen zu Cookies und dazu, wie Sie die Cookie-Einstellungen ändern können, finden Sie [hier](#).


[Weiter](#)

Meine Listen: [Teilleiste](#) | [Geschichte & Bookmarks](#)

Begrüßung, [Gast](#)

[Anmelden](#)

[Registrieren](#)

 [Deutsch](#)

[Themen](#) | [Ressourcen](#) | [Inhalt](#) | [Mitglieder](#) | [Designzentrum](#) | [Shop](#)

 [Load Google Translate](#)

[Alle Gemeinschaften](#) > [Pumping Station: One](#) > [Blog](#) > 2011 > Mai > 08

Pumping Station: One



 [Teilen](#)



 [Feeds anzeigen](#)

Blog filtern

Nach Autor:

[Drew Fustini](#)

[ashanan](#)

[sblaszak](#)

[Ibittner](#)

[hckrdan](#)

[billmania](#)

Nach Datum:

Nach Tag:

[arduino](#) [biology](#) [body](#)
[chicago](#) [diy](#)
[education](#) [gghc](#)
[hackerspace](#)
[hackerspaces](#)
[make](#) [maker](#) [ps1](#)
[psone](#)
[pumpingstationone](#)
[schools](#)

Aktuelle Einträge

[element14 Takes a Field Trip to Pumping Station: One](#)

[From EAGLE to finished PCB in 2 hours](#)

[Pumping Station: One in Make magazine](#)

[Hackerspace member creates universal Android dock](#)

[Biosensor Q & A](#)

[Hackerspaces: Y'all rock!](#)


[Ouch! Sensing Galvanic Skin Response \(GSR\)](#)


[Down to the wire - GGHC Biosensor Array build recap](#)

[Biosensor crunch time](#)

[Biosensor Array Update](#)

Eingehende Links

 [Re: Have a question about Arduino? Ask me!](#)

 [Re: Simple project for 10-11 year old.](#)

 [Arduino sensing galvanic skin response](#)




Ouch! Sensing Galvanic Skin Response (GSR)

Gepostet von [Drew Fustini](#) in [Pumping Station: One](#) am 08.05.2011 18:02:20

Howdy,

The primary sensor I've been prototyping for the Pumping Station: One Biosensor Array is the galvanic skin response, or GSR, sensor. GSR is a measurement of the electrical conductance of the skin. Sweating causes changes in the conductance, which offers an indication of emotional excitement, because the sweat glands are controlled by the sympathetic nervous system. GSR does not offer a fine grained indication of emotion, since it does not distinguish between the many different emotions which elicit a change in skin conductance.




GSR graphed on [SparkFun LCD shield](#)


If you have a multimeter on hand, then you can measure the resistance between two fingers by pressing one probe against each finger. The range for the resistance of skin is typically 50k to 10M Ohm (per [Sean Montgomery](#)). Skin conductance is the reciprocal of that resistance. Thus 50k Ohm is 20 uS (micro Siemens, not Seconds) and 10M Ohm is 0.1 uS. To summarize, skin conductance is inversely proportional to skin resistance.

However, if one just looks at their skin resistance on a DMM, then it will be very difficult to determine when their skin is responding to emotional changes. Thus, a circuit is required which produces an output voltage proportional to the change in skin resistance. The circuit needs to filter out noise and amplify the GSR signal. This output voltage can then read by any microcontroller (an Arduino for this project) and graphed over time in software.

I tried many [different approaches](#) when prototyping GSR, but I found a modified version of the [Truth Meter](#) circuit by Sean Montgomery worked the best for our application:




baseline R_{skin}
~0.48Hz cut



Low-Pass Filter
Filter out high freq noise
~4.8Hz cut


Amplification
Increase signal range
to light up LED
(100x)

Sean built this circuit so that no microcontroller is needed as it employs both a low & high pass filter to create a 0.5 Hz to 5 Hz band pass which works well for GSR since it is a slow 1 to 2 Hz signal. The low-pass filter cuts off high frequency noise above 5 Hz such as 60 Hz noise from AC power. The high-pass filter cuts off frequencies below 0.5 Hz, or 2 seconds.





Truth Meter uses a 9V for power and an LED for output. The brightness correlates to the GSR magnitude. (Photo by Jordan Bunker)

In effect, the high-pass filtering subtracts the baseline average skin resistance leaving the only change in skin resistance within the 1-2 second range of GSR. The result is that the GSR sensor is able to auto-calibrate for each user regardless of the the baseline skin resistance. Essentially, the Truth Meter circuit produces just the GSR events, or spikes, where an emotional response occurred which is illustrated by this graph on Sean's [website](#):




Sean's Truth Meter circuit worked really well for our project as the voltage output of the circuit is already filtered and can be simply read by disconnecting the LED and instead connecting the output resistor to the Arduino via an analog input. The complexity of the Arduino code is reduced as no additional filtering needs to be done in software.






Biosensor GSR circuit prototype based on the Truth Meter connected to Arduino analog input.

[Arduinoscope](#), a Processing sketch, is running and graphing the output the Arduino is sending via serial link over USB. The spike pictured below is the result of me poking myself in the leg with the leads of an LED to illicit pain:




I found slapping myself also worked well too:



Safety Tip:

As an aside, always have your laptop unplugged from AC power when doing biosensing prototyping. First and most important reason is safety. Second reason is that the analog inputs will have 60 Hz noise imposed on their waveforms. I found this to be the case even with the bandpass filter in the GSR circuit. The above screenshot was taken when the laptop was plugged in AC and the waveform looked much smoother when laptop is running off battery. For our actual biosensor array, a Bluetooth module & 6xAA batteries are used so that there is no connection to laptop or AC power.

After prototyping on breadboard with good results, I made the Biosensor Array GSR shield which is pictured below. It is stackable with the ECG shield and has header for the BlueSMiRF bluetooth module. It is essentially the Truth Meter circuit but with pots for the important resistors to enable maximum calibration by the user: 1M Ω m (skin voltage divider), 10k Ω m (non-inverting reference voltage divider, substituted for the diodes) and 100k Ω m (gain of final op-amp):




These simple finger straps below connect to header on the GSR shield and are extended for actual usage by our biosensor array cabling system. Based on the Truth Meter instructions, I built the straps from copper foil & velcro tape I got at Jo-Ann Fabrics. After building several pairs, I went out and got some stranded wire as it makes a much better solder joint than solid core wire on the copper foil. Also, I made sure to use lead-free solder as the solder joints are in direct contact with fingers during usage.



And finally, if your interested in building your own Truth Meter, the circuit is featured in Make Magazine Vol 26 (Spring 2011) in the "Biosensing" article by [Ira M. Laefsky](#) & [Sean M. Montgomery](#):

- Make Magazine: The Truth Meter
 - <http://makeprojects.com/Project/The-Truth-Meter/703/1>
- MakerShed Truth Meter kit:
 - <http://blog.makezine.com/archive/2011/04/new-in-the-maker-shed-galvanic-skin-response-kit.html>
- Truth Meter kit assembly & usage video by Make:

In my next blog post, I will share the other circuits I prototyped and [challenges encountered](#) along with how I plan to improve the GSR sensor in the future, like refining the LCD display:



Cheers,
Drew
<http://twitter.com/pdp7>

23357 Ansichten

Tags: [education](#), [schools](#), [body](#), [arduino](#), [diy](#), [skin](#), [make](#), [maker](#), [chicago](#), [hackerspace](#), [pumpingstationone](#), [ps1](#), [psone](#), [response](#), [gghc](#), [hackerspaces](#), [biology](#), [gsr](#), [galvanic](#)



6 Kommentare

[Login](#) or [Register](#) to comment



[DAB](#) 08.05.2011 22:51

Very interesting.

Thanks,
DAB

Gefällt mir (0)



[paulzee](#) 09.05.2011 05:08

Great stuff - nicely done Drew!

I'm thinking I'd love to see the OpenLab incorporate some of your sensor work as add-on experimenters kits. I'd love to kick some ideas on that - once the dust has settled 😊

👍 Gefällt mir (0)



Drew Fustini 10.05.2011 19:15 (als Antwort auf paulzee)

Thanks all.

@Paul, that would be great. I really liked the professional design of the OpenLab. I used NI's expensive, proprietary, Windows-only ELVIS in a couple classes and it was terrible. I think the the OpenLab would do much, much better job.

I remember from the Signal interview that ya guys got your PCB quickturned by piggybacking on a local business. Any plans to do kits of the OpenLab?

And, yeah, that would be great to try to interface the biosensors with it once things have calmed down a bit. I think everyone has been catching up on their day jobs after crunchtime 😊

Cheers,
Drew

👍 Gefällt mir (0)



Drew Fustini 29.11.2013 19:39

fyi - I believe the code we used is here: https://github.com/pdp7/ps1biosensor/tree/master/ps1biosensor_arduino

👍 Gefällt mir (0)



kat1171 29.03.2015 16:57

On the Make site it's just a circuit. On here you use an Arduino board. I want to stream the data live (kind of like processing)- how should I do that?

👍 Gefällt mir (0)



satrio_priyono 30.03.2015 16:56

Mr drew, is it possible using gsr for measuring human skin moisture ? based on your schematic above, how to connect it to arduino?

👍 Gefällt mir (0)

[Login](#) or [Register](#) to comment

Themen

3D-Druck
Arduino
Business of Engineering
Embedded-Technologie
Industrial Automation & Robotics
Internet of Things
Freie Hardware
Power & Energy
Raspberry Pi
Raspberry Pi-Zubehör
Raspberry Pi-Projekte
Get Started With Pi
Sensoren/MEMS
Einplatinencomputer
Messtechnik
Wearables

Ressourcen

Experten fragen
The Ben Heck Show
Designsoftware EAGLE von CadSoft
Austausch von Codes
Design-Wettbewerbe
Feedback & Support
Learning Center
Informationen zur Gesetzgebung
Hersteller
News
Leiterplatten-Prototyping
Beschaffungslösungen
RoadTest
STEM Academy
element14-TV
Webinare und Schulungen

Inhalt

Blog-Beiträge
Dokumente
Diskussionen
Umfragen
Videos
Veranstaltung

Designzentrum

Produkte
Analog Demo Boards
Entwicklungsplattformen & Development Kits
Emulatoren & Debugger
Software
IDEs und Compiler
OS & Middleware
Test & Simulation
EDA Tools

Angebote
Technologien
Atmel Xplained
CircuitStudio PCB Design
Freedom-Plattform von Freescale
MATLAB for Students
LPCXPRESSO
EcoSystem
Einplatinencomputer
STM Discovery
TI Launchpads
Timesys Linux Support

Mitglieder

Mitgliederverzeichnis
Mitglied des Monats
Rangliste & Punkte
Experten fragen
Top-Mitglieder
Warum Mitglied werden?
Diese Woche in der element14 Community

Shop

Zum deutschen Online-Shop
Ein anderes Land auswählen

element14 COMMUNITY

element14 ist die erste Online-Community speziell für Ingenieure. Schließen Sie mit Ihren Kollegen und erhalten kompetente Antworten auf Ihre Fragen.

Über uns
Unsere Geschichte

Folgen Sie uns



Mobile App

🍏 Download iOS app
🤖 Laden Android App

[View All >>](#)

Circuit Design & Tools

[Altium PCB Design](#)

[EAGLE PCB Design](#)

[PCB Fabrication](#)

[PCB Assembly](#)

[Design Services](#)

Find

[Suche & Filter](#)

[Technial Library](#)

[Where did theknode go?](#)

[Feedback & Support](#) | [FAQs](#) | [Allgemeine Geschäftsbedingungen](#) | [Datenschutz](#) | [Sitemap](#)

A Premier Farnell Company

© 2009-2015 Premier Farnell plc. All Rights Reserved.

Premier Farnell plc, registered in England and Wales (no 00876412), registered office: Farnell House, Forge Lane, Leeds LS12 2NE

Powered by **jive**

Feedback Survey

When you are done with your visit to our site, please fill out our feedback survey.

Start the Survey Now!

[no thanks\[x\]](#)

powered independently by Qualtrics